



NOTES:

1. USE 3/4" TEFLON TAPE AT ALL SCH 40 ELLS
2. INSTALL RISERS PERPENDICULARLY PLUMB TO ADJACENT GRADE
3. INSTALL RISERS 12" FROM WALL OR FENCE
4. ADJUST NOZZLES TO PREVENT OVERSPRAY ONTO HARDSCAPE
5. USE POP-UP SPRAY HEADS @ TOE OF SLOPE & WITHIN 8' OF SIDEWALK, TURF OR CURBING

LD Consulting 2012 (Any deviation or reproduction of this design must be approved in writing by Valley-Wide Recreation & Park District)



VALLEY-WIDE RECREATION & PARK DISTRICT

SHRUB SPRAY ON GRADE

IR-37

REV. 2012