

NOTES:

- 1. USE 3/4" TEFLON TAPE AT ALL SCH 40 ELLS
- 2. INSTALL RISERS PERPENDICULARLY PLUMB TO ADJACENT GRADE
- 3. INSTALL RISERS 12" FROM WALL OR FENCE
- 4. ADJUST NOZZLES TO PREVENT OVERSPRAY ONTO HARDSCAPE
- 5. USE POP-UP ROTORS @ TOE OF SLOPE & WITHIN 8' OF SIDEWALK, TURF OR CURBING

LD Consulting 2012 (Any deviation or reproduction of this design must be approved in writing by Valley-Wide Recreation & Park District)



VALLEY-WIDE RECREATION & PARK DISTRICT

SHRUB ROTOR ON GRADE

IR-40

REV. 2012