



NOTES:

1. USE 3/4" TEFLON TAPE WHERE ELL MEETS SCH 40 TEE
2. INSTALL HEADS PERPENDICULARLY PLUMB TO ADJACENT GRADE
3. ADJUST NOZZLES TO PREVENT OVERSPRAY ONTO HARDSCAPE
4. INSTALL HEADS 2" FROM HARDSCAPE EDGE IN TURF AREAS WHERE ALLOWED PER AB 1881
5. INSTALL HEADS 6" FROM WALLS IN PLANTER AREAS WHERE ALLOWED PER AB 1881
6. ALL HEADS ADJACENT TO CONCRETE SURFACE SHALL BE FLUSH TO TOP OF CONCRETE

LD Consulting 2012 (Any deviation or reproduction of this design must be approved in writing by Valley-Wide Recreation & Park District)



VALLEY-WIDE RECREATION & PARK DISTRICT

POP-UP SPRAY HEAD

IR-39

REV. 2012