

- 1. USE 3/4" TEFLON TAPE AT ALL SCH 40 ELLS
- 2. INSTALL RISERS PERPENDICULARLY PLUMB TO ADJACENT GRADE
- 3. INSTALL RISERS 12" FROM WALL OR FENCE
- 4. ADJUST NOZZLES TO PREVENT OVERSPRAY ONTO HARDSCAPE
- 5. USE POP-UP ROTORS WITHIN 8' OF SIDEWALK, TURF OR CURBING

LD Consulting 2012 (Any deviation or reproduction of this design must be approved in writing by Valley-Wide Recreation & Park District)



## **VALLEY-WIDE RECREATION & PARK DISTRICT**

SHRUB ROTOR ON RISER

IR-42

REV. 2012